

Fit Factory Project Report

by Ethan Chen

The Device

The Device is made up of the Sparkfun Thing Dev, an accelerometer, and a particle sensor. The code below uses data from the accelerometer to figure out how many reps the user has completed of an exercise. It also analyzes the data from the particle sensor using rising and falling edges of the data to find out the users heart rate. The application used a modified Demo 4 in order to send data to the Azure Hub. It sends the average heart rate over the ten seconds as well as the reps completed.

The Following is the Arduino IDE code (ends on page 6, look for red message):

```
#include <ESP8266WiFi.h>
#include <WiFiClientSecure.h>
#include <WiFiUdp.h>
#include <AzureIoTHub.h>
#include <AzureIoTProtocol_MQTT.h>
#include <AzureIoTUtility.h>
#include "config.h"
```

```
static bool messagePending = false;
static bool messageSending = true;
static char *connectionString;
static char *ssid;
static char *pass;
static int interval = INTERVAL;
#include "MAX30105.h"
#include "SparkFunLSM6DS3.h"
#include "SPI.h"
#include <Wire.h>
#include "heartRate.h"
```

```
MAX30105 particleSensor;
const byte RATE_SIZE = 4; //Increase this for more averaging. 4 is good.
byte rates[RATE_SIZE]; //Array of heart rates
byte rateSpot = 0;
long lastBeat = 0; //Time at which the last beat occurred
```

```
float beatsPerMinute;
int beatAvg;
```

```
LSM6DS3 myIMU; //Default constructor is I2C, addr 0x6B
```

```
float startY = 0;  
float curY = 0;  
float curPos = 0;  
bool wentUp = false;  
int step = 0;  
int lastRead = 0;
```

```
void blinkLED()  
{  
    digitalWrite(LED_PIN, HIGH);  
    delay(500);  
    digitalWrite(LED_PIN, LOW);  
}
```

```
void initWifi()  
{  
    // Attempt to connect to Wifi network:  
    Serial.printf("Attempting to connect to SSID: %s.\r\n", ssid);  
  
    // Connect to WPA/WPA2 network. Change this line if using open or WEP network:  
    WiFi.begin(ssid, pass);  
    while (WiFi.status() != WL_CONNECTED)  
    {  
        // Get Mac Address and show it.  
        // WiFi.macAddress(mac) save the mac address into a six length array, but the endian may  
        be different. The huzzah board should  
        // start from mac[0] to mac[5], but some other kinds of board run in the oppsite direction.  
        uint8_t mac[6];  
        WiFi.macAddress(mac);  
        Serial.printf("You device with MAC address %02x:%02x:%02x:%02x:%02x:%02x connects  
to %s failed! Waiting 10 seconds to retry.\r\n",  
            mac[0], mac[1], mac[2], mac[3], mac[4], mac[5], ssid);  
        WiFi.begin(ssid, pass);  
        delay(10000);  
    }  
    Serial.printf("Connected to wifi %s.\r\n", ssid);  
}
```

```
void initTime()  
{  
    time_t epochTime;
```

```

configTime(0, 0, "pool.ntp.org", "time.nist.gov");

while (true)
{
    epochTime = time(NULL);

    if (epochTime == 0)
    {
        Serial.println("Fetching NTP epoch time failed! Waiting 2 seconds to retry.");
        delay(2000);
    }
    else
    {
        Serial.printf("Fetched NTP epoch time is: %lu.\r\n", epochTime);
        break;
    }
}
}

```

//The callibration function records heartrate values until it finds 2 that are unique and above 60

```

void callibration(){
    beatsPerMinute = 0.0;
    float first = 0.0;
    float second = 0.0;
    bool done = false;
    while(!done){
        long irValue = particleSensor.getIR();

        if (checkForBeat(irValue) == true)
        {
            //We sensed a beat!
            long delta = millis() - lastBeat;
            lastBeat = millis();

            beatsPerMinute = 60 / (delta / 1000.0);

            if (beatsPerMinute < 255 && beatsPerMinute > 20)
            {
                rates[ratesSpot++] = (byte)beatsPerMinute; //Store this reading in the array
                ratesSpot %= RATE_SIZE; //Wrap variable
            }
        }
    }
}

```

```

    if(first < 60){
        first = beatsPerMinute;
    }else{
        second = beatsPerMinute;
    }
    if(first > 60 && second > 60 && first!=second){
        done = true;
    }
    /*
    if(beatsPerMinute>60) {
        done = true;
    }
    */
}

Serial.print("IR=");
Serial.print(irValue);
Serial.print(", BPM=");
Serial.print(beatsPerMinute);

if (irValue < 50000)
    Serial.print(" No finger?");

Serial.println();
}
}

static IOTHUB_CLIENT_LL_HANDLE iotHubClientHandle;
void setup()
{
    pinMode(LED_PIN, OUTPUT);

    initSerial();
    delay(2000);
    readCredentials();

    initWifi();
    initTime();
    initSensor();

```

```

    iotHubClientHandle = IoTHubClient_LL_CreateFromConnectionString(connectionString,
MQTT_Protocol);
    if (iotHubClientHandle == NULL)
    {
        Serial.println("Failed on IoTHubClient_CreateFromConnectionString.");
        while (1);
    }

    IoTHubClient_LL_SetMessageCallback(iotHubClientHandle, receiveMessageCallback,
NULL);
    IoTHubClient_LL_SetDeviceMethodCallback(iotHubClientHandle, deviceMethodCallback,
NULL);
    IoTHubClient_LL_SetDeviceTwinCallback(iotHubClientHandle, twinCallback, NULL);

    myIMU.begin();
    startY = myIMU.readFloatAccelY()*50+5;

    Serial.println("Calibrating:");
    calibration();
    Serial.println("Done Calibrating");

}

static int messageCount = 1;
long timer= millis();
//while(millis())<time + 10000){

void loop()
{
    //modified a sparkfun heart rate example to calculate the heart rate using the MAX30105 with
the following algorithm
    long irValue = particleSensor.getIR();

    if (checkForBeat(irValue) == true)
    {
        long delta = millis() - lastBeat;
        lastBeat = millis();
        beatsPerMinute = 60 / (delta / 1000.0);

        if (beatsPerMinute < 255 && beatsPerMinute > 20)
        {

```

```

        rates[rateSpot++] = (byte)beatsPerMinute; //Store this reading in the array
        rateSpot %= RATE_SIZE; //Wrap variable

    }
}

//In order to track user movement, I used the following formula to record movements.
curY = myIMU.readFloatAccelY()*50+5;

if(millis()-lastRead > 500){
    if(abs(curY) > 10 + startY){
        if(!wentUp){
            wentUp=true;
            //step++;
        }
    }
    if(abs(curY) < 3 + startY){
        if(wentUp){
            wentUp = false;
            step++;
            lastRead = millis();
        }
    }
}

// I modified the message payload to only update every 10 seconds.
if (!messagePending && messageSending&& millis(>timer+10000)
{
    char messagePayload[MESSAGE_MAX_LEN];

    // I modified the temperatureAlert function to also include the beats per minute and steps
    // calculated in the 10 second period
    bool temperatureAlert = readMessage(messageCount,
    messagePayload,beatsPerMinute,step);
    sendMessage(iotHubClientHandle, messagePayload, temperatureAlert);
    messageCount++;
    step = 0;
    //delay(interval);
    timer = millis();
}
IoTHubClient_LL_DoWork(iotHubClientHandle);
delay(10);
}

```

The End of Arduino IDE code!

The Cloud

The app utilizes the Azure IoT Hub and Web Application services. The Sparkfun thing takes data readings and sends information to the IoT Hub. The IoT Hub has endpoints that allow the web application to access this data. I used the code from Demo4 for the server side of the app. The Hub basically serves as a middleman between the application and the device and makes the communication smooth and simple. The server reads data from the hub and broadcasts it to all of the clients.

```
server.js
1  const express = require('express');
2  const http = require('http');
3  const WebSocket = require('ws');
4  const moment = require('moment');
5  const path = require('path');
6  const iotHubClient = require('./IoThub/iot-hub.js');
7
8  const app = express();
9
10 app.use(express.static(path.join(__dirname, 'public')));
11 app.use(function (req, res, next) {
12   res.redirect('/');
13 });
14
15 const server = http.createServer(app);
16 const wss = new WebSocket.Server({ server });
17
18 // Broadcast to all.
19 wss.broadcast = function broadcast(data) {
20   wss.clients.forEach(function each(client) {
21     if (client.readyState === WebSocket.OPEN) {
22       try {
23         console.log('sending data ' + data);
24         client.send(data);
25       } catch (e) {
26         console.error(e);
27       }
28     }
29   });
30 };
31
32 var iotHubReader = new iotHubClient(process.env['Azure.IoT.IoTHub.ConnectionString'], process
33 iotHubReader.startReadMessage(function (obj, date) {
34   try {
35     console.log(date);
36     date = date || Date.now()
37     wss.broadcast(JSON.stringify(Object.assign(obj, { time: moment.utc(date).format('YYYY:MM:
38   } catch (err) {
39     console.log(obj);
40     console.error(err);
41   }
42 });
43
44 var port = normalizePort(process.env.PORT || '3000');
45 server.listen(port, function listening() {
46   console.log('Listening on %d', server.address().port);
47 });
48
```

```

52
53 function normalizePort(val) {
54   var port = parseInt(val, 10);
55
56   if (isNaN(port)) {
57     // named pipe
58     return val;
59   }
60
61   if (port >= 0) {
62     // port number
63     return port;
64   }
65
66   return false;
67 }
68

```

The Application

The HTML document formats the information and creates some simple functionality to the page like inputs and buttons. It also features a picture of a fat person to start that gets thinner as a user gets closer to the goal. This gives a simple way to visualize the workout progress.


```

1 <html>
2
3 <head>
4   <title>Fit Factory</title>
5   <script src="javascripts/jquery-2.1.4.min.js" type="text/javascript" charset="utf-8"></script>
6   <script src="javascripts/Chart.min.js" type="text/javascript" charset="utf-8"></script>
7   <script src="javascripts/index.js" type="text/javascript" charset="utf-8"></script>
8   <link href="stylesheets/style.css" rel="stylesheet" />
9   <style>
10     * {
11       box-sizing: border-box;
12     }
13
14     .row {
15       display: flex;
16     }
17
18     /* Create two equal columns that sits next to each other */
19     .column {
20       flex: 50%;
21       padding: 10px;
22     }
23   }
24 </style>
25 </head>
26
27 <body>
28   <canvas id="myChart" width="400" height="100"></canvas>
29   <p id="demo"></p>
30   <div>
31     <form id="frm1" >
32       Age: <input type="text" name="fname" >
33       Weight: <input type="text" name="lname" >
34     </form>
35     <button onClick="start()">Start Workout</button>
36     <p id="demo"></p>
37     <script>
38       function start(){
39         var x = document.getElementById("frm1");
40         h = x.elements[0].value
41         w = x.elements[1].value
42         document.getElementById("age").innerHTML = "Age: " + h;
43         document.getElementById("wt").innerHTML = "Weight: " + w;
44       }
45     </script>
46     <div class="row">
47       <div class="column">
48         <p id="msgs">Messages Received: 0</p>

```

```

45     </script>
46     <div class="row">
47         <div class="column">
48             <p id="msgs">Messages Received: 0</p>
49             <p id="age">Age: ?</p>
50             <p id="wt">Weight: ?</p>
51             <p id="state">State: Calibration</p>
52             <p id="restinghr">Resting Heartrate: ?</p>
53         </div>
54         <div class="column">
55             <p id="reps">Total Reps: </p>
56             <p id="rps">Avg Reps/Second: </p>
57             <p id="cals">Calories Burnt: 0</p>
58             <p id="activehr">Average Active Heartrate: ?</p>
59         </div>
60         <div class="column">
61             <img id="fatty" src = "images/Fat5.png" alt = "FattestGuy" style="width:200px;
62                 height:200px;">
63         </div>
64     </div>
65 </body>
66 </html>
67
68
69
70
71

```

The Javascript code is where most of the calculations are performed. Most of the code is executed every time a message is received from the server. It shifts between various states and the display changes accordingly. In the screenshotted code below, there are comments that discuss this in more detail. The key idea here was to keep updating the information so that the user can have a live feed of data during the workout.

```

1 $(document).ready(function () {
2     //initialize variables to track information as the app is running
3     var messageCount = 0,
4         activeMessages = 0,
5         restingMessages = 0,
6         calories = 0,
7         calorieGoal = 0,
8         totalHeartrate = 0,
9         restingHeartrate = 0,
10        activeHeartrate = 0,
11        targetRate = 0,
12        age = 0,
13        agestr = "",
14        weight = 0,
15        totalreps = 0,
16        infoSet = false,
17        currentSets = 0,
18        state = 0,
19        currentStateDuration = 0,
20        restDuration = 30,
21        setDuration = 60,
22        totalSets = 4,
23        fatlevel = 5;
24
25    //creates an array that tells script where to find images to display
26    var images = [], x = 0;
27    images[0] = "../images/Fat0.png";
28    images[1] = "../images/Fat1.png";
29    images[2] = "../images/Fat2.png";
30    images[3] = "../images/Fat3.png";
31    images[4] = "../images/Fat4.png";
32    images[5] = "../images/Fat5.png";
33
34    //stores workout messages
35    var workouts = [], y = 0;
36    workouts[0] = "Do Jumping Jacks for 60 Seconds.";
37    workouts[1] = "Do High Knees for 60 Seconds.";
38    workouts[2] = "Do Jumping Squats for 60 Seconds.";
39    workouts[3] = "Do Butt Kickers for 60 Seconds.";
40
41
42    //creates a chart that plots the data received from the server
43    var timeData = [],
44        heartData = [],
45        movementData = [];
46    var data = {
47        labels: timeData,
48        datasets: [

```

```

46 var data = {
47   labels: timeData,
48   datasets: [
49     {
50       fill: false,
51       label: 'Hearttrate',
52       yAxisID: 'Hearttrate',
53       borderColor: "rgba(255, 0, 0, 1)",
54       pointBoarderColor: "rgba(255, 0, 0, 1)",
55       backgroundColor: "rgba(255, 0, 0, 0.4)",
56       pointHoverBackgroundColor: "rgba(255, 0, 0, 1)",
57       pointHoverBorderColor: "rgba(255, 0, 0, 1)",
58       data: heartData
59     },
60     {
61       fill: false,
62       label: 'Movement',
63       yAxisID: 'Movement',
64       borderColor: "rgba(24, 120, 240, 1)",
65       pointBoarderColor: "rgba(24, 120, 240, 1)",
66       backgroundColor: "rgba(24, 120, 240, 0.4)",
67       pointHoverBackgroundColor: "rgba(24, 120, 240, 1)",
68       pointHoverBorderColor: "rgba(24, 120, 240, 1)",
69       data: movementData
70     }
71   ]
72 };
73
74 var basicOption = {
75   title: {
76     display: true,
77     text: 'Hearttrate & Movement Real-time Data',
78     fontSize: 36
79   },
80   scales: {
81     yAxes: [{
82       id: 'Hearttrate',
83       type: 'linear',
84       scaleLabel: {
85         labelString: 'Hearttrate(bpm)',
86         display: true
87       },
88       position: 'left',
89     }, {
90       id: 'Movement',
91       type: 'linear',
92       scaleLabel: {
93         labelString: 'Movement(steps)',

```

```

92         stateLabel: {
93             labelString: 'Movement(steps)',
94             display: true
95         },
96         position: 'right'
97     }]
98 }
99 };
100
101 //Get the context of the canvas element we want to select
102 var ctx = document.getElementById("myChart").getContext("2d");
103 var optionsNoAnimation = { animation: false };
104 var myLineChart = new Chart(ctx, {
105     type: 'line',
106     data: data,
107     options: basicOption
108 });
109
110
111 //connects to the server
112 var ws = new WebSocket('wss://' + location.host);
113 ws.onopen = function () {
114     console.log('Successfully connect WebSocket');
115 };
116
117 //every time the servers sends a message, this function is called
118 ws.onmessage = function (message) {
119     /*
120     The app tracks its state, and each possible state is assigned a numerical value
121     0: Initial Calibration, the app waits for the device to connect to the IoT hub and start
122     sending messages and the user to input their age and weight
123     1: Initial Reading, the user holds still while the particle sensor takes readings of their
124     pulse, these readings are plotted and the app also displays the average resting heart
125     rate based on these readings
126     2: Exercise, the app displays what exercise the user has to do and plots movement data
127     from the accelerometer which shows how many reps the user did in the last 10 seconds
128     3: Rest, the user holds still again as more heartrate readings are displayed on the graph.
129     These readings are elevated now that the user has been active. These readings are used
130     to calculate calories burned.
131     4: Workout Complete, the app stops plotting data and displays some final statistics
132
133     note: since we built our project on the code from Demo 4, the data sent by the server
134     still has some of its older naming. The heartrate data is stored in obj.temperature and
135     the movement data is stored in obj.humidity
136     */
137
138     //increment the total messageCount and current state duration
139     messageCount++;

```

```

137
138 //increment the total messageCount and current state duration
139 messageCount++;
140 currentStateDuration += 10;
141
142 console.log('receive message' + message.data);
143 try {
144     var obj = JSON.parse(message.data);
145     if(!obj.time || !obj.temperature) {
146         return;
147     }
148
149     //In the Exercise state, set heartrate to 0 on the graph because the readings
150     //are inaccurate
151     if(state == 2){
152         obj.temperature = 0;
153     }
154     //In the Rest state, set movement to 0 on the graph because these movements are not
155     //actual reps
156     if(state != 2){
157         obj.humidity = 0;
158     }
159
160     //Only plot points after calibration and before workout ends
161     if(state != 0 && state != 4){
162         timeData.push(messageCount*10);
163         heartData.push(obj.temperature);
164         movementData.push(obj.humidity);
165     }
166     // only keep no more than 50 points in the line chart
167     const maxLen = 50;
168     var len = timeData.length;
169     if (len > maxLen) {
170         timeData.shift();
171         heartData.shift();
172         movementData.shift();
173     }
174
175
176     /*
177     The two sections below add the readings to a variable that track the total while
178     incrementing a count that shows how many readings of that type have been stored
179     in this sum. We can find the average value for each by dividing by these reading counts.
180     A new message is sent to the server every 10 seconds so it is easy to convert between
181     messages and time in seconds.
182     */

```



```

183 //updating total heartrate based on new data during rest states
184 if(state == 1 || state == 3){
185     restingMessages++;
186     totalHeartrate += obj.temperature;
187 }
188 //updating rep data based on new data during active states
189 if(state == 2){
190     activeMessages++;
191     totalreps += obj.humidity;
192     document.getElementById("reps").innerHTML = "Total Reps: " + totalreps;
193     document.getElementById("rps").innerHTML = "Avg Reps/Second: " + (totalreps/(activeMessages*10)).toFixed(3);
194 }
195
196 //updates the chart based on new data
197 myLineChart.update();
198
199
200 //updates image and grade based on how many calories have been burnt out of the goal
201 var img = document.getElementById("fatty");
202
203 if (fatlevel == 5 && calories/calorieGoal >= 0.2) {
204     fatlevel = 4;
205     img.src = images[fatlevel];
206     img.alt = "fat4";
207     document.getElementById("grade").innerHTML = "Fitness Grade: D" ;
208 }
209
210 if (fatlevel == 4 && calories/calorieGoal >= 0.4) {
211     fatlevel = 3;
212     img.src = images[fatlevel];
213     img.alt = "fat3";
214     document.getElementById("grade").innerHTML = "Fitness Grade: C" ;
215 }
216
217 if (fatlevel == 3 && calories/calorieGoal >= 0.6) {
218     fatlevel = 2;
219     img.src = images[fatlevel];
220     img.alt = "fat2";
221     document.getElementById("grade").innerHTML = "Fitness Grade: B" ;
222 }
223
224 if (fatlevel == 2 && calories/calorieGoal >= 0.8) {
225     fatlevel = 1;
226     img.src = images[fatlevel];
227     img.alt = "fat1";
228     document.getElementById("grade").innerHTML = "Fitness Grade: A" ;
229 }
230
231 if (fatlevel == 1 && calories/calorieGoal >= 1) {
232     fatlevel = 0;

```

```

229     if (fatlevel == 1 && calories/calorieGoal >= 1) {
230         fatlevel = 0;
231         img.src = images[fatlevel];
232         img.alt = "skinniest";
233         document.getElementById("grade").innerHTML = "Fitness Grade: A++" ;
234     }
235
236     /*
237     shifting from calibration to initial rest state
238     retrieves height and weight from HTML document
239     this cannot happen until the app receives a message from the server
240     messages are only sent after the device has calibrated
241     */
242     if(!infoSet){
243         agestr = document.getElementById('age').innerHTML;
244         if(agestr.slice(-1) != "?"){
245             infoSet = true;
246             age = parseInt(agestr.slice(agestr.indexOf(" ")));
247             var wtstr = document.getElementById('wt').innerHTML;
248             weight = parseInt(wtstr.slice(wtstr.indexOf(" ")));
249             state = 1;
250             document.getElementById("state").innerHTML = "State: Rest(Taking Initial Heartrate Readings)";
251             currentStateDuration = 0;
252             document.getElementById("inputs").style.display = 'none';
253             document.getElementById("msg").innerHTML = "Hold still as the sensor takes heart readings";
254         }
255     }
256
257     /*
258     shifting from initial rest to exercise after the duration exceeds threshold
259     based on the collected data, we now display resting heart rate and target calories
260     */
261     if(state == 1 && currentStateDuration == restDuration){
262         state = 2;
263         document.getElementById("state").innerHTML = "State: Exercise";
264         currentStateDuration = 0;
265         restingHeartrate = totalHeartrate/restingMessages;
266         document.getElementById("restinghr").innerHTML = "Resting Heartrate: " + restingHeartrate.toFixed(3);
267         targetRate = (220 - age)*0.62;
268         calorieGoal = ((age*0.2017) - (weight*0.09036) + (targetRate*0.6309) - 55.0969)*(setDuration*totalSets/251.04);
269         document.getElementById("goal").innerHTML = "Calorie Target: " + calorieGoal.toFixed(3);
270         totalHeartrate = 0;
271         restingMessages = 0;
272         document.getElementById("msg").innerHTML = workouts[currentSets];
273     }
274
275 }
276

```




```

276 //shifting from exercise to rest after set duration is exceeded
277
278 if(state == 2 && currentStateDuration == setDuration){
279     state = 3;
280     document.getElementById("state").innerHTML = "State: Rest";
281     document.getElementById("msg").innerHTML = "Take a moment to catch your breath and hold still as the sensor takes a reading";
282     currentStateDuration = 0;
283 }
284
285 /*
286 shifting from rest to exercise or end of workout
287 calculates average active heartrate and calories burnt based on this reading
288 depending on how many sets are completed, this either shifts back to the exercise state
289 or to the end state
290 */
291 if(state == 3 && currentStateDuration == restDuration){
292     currentSets++;
293     currentStateDuration = 0;
294     activeHeartrate = totalHeartrate/restingMessages;
295     document.getElementById("activehr").innerHTML = "Average Active Heartrate: " + activeHeartrate.toFixed(3);
296     //calories burned = [(age + 0.2017) - (weight + 0.09036) + (Heart Rate x 0.6309) - 55.0969] x Time / 4.184";
297     calories = ((age*0.2017) - (weight*0.09036) + (activeHeartrate*0.6309) - 55.0969)*(activeMessages/25.104);
298     document.getElementById("cals").innerHTML = "Calories Burnt: " + calories.toFixed(3);
299     if(currentSets == totalSets){
300         state = 4;
301         document.getElementById("state").innerHTML = "State: Workout Complete";
302         document.getElementById("msg").innerHTML = "Well done, you burned " + calories.toFixed(3) + " out of the " + totalCalories.toFixed(3) + " calories";
303     }
304     else{
305         state = 2;
306         document.getElementById("state").innerHTML = "State: Exercise";
307         document.getElementById("msg").innerHTML = workouts[currentSets];
308     }
309 }
310
311 } catch (err) {
312     console.error(err);
313 }
314 };
315 });
316 });
317

```


This Web Application, named Fit Factory, is a workout analysis application that uses Sparkfun ESP8266 board connected to a MAX30105 particle sensor and an LSM6DS3 accelerometer to track the user's heart rate and movements.




I configured a standard workout phone sleeve to hold the sparkfun and the connected sensors to fit on my arm while performing the workout.




The Web Application begins with this empty graph (which later plots the user's heart rate and actions performed during 10 second intervals), and information about the workout below. I also include an image of a fat orange human figure to represent the starting place for the workout. The goal was to have this fat figure get skinnier as the workout progressed.




One of the variables at the bottom “State”, serves as a guide as to the stage in the workout that the user is currently in. During the “Calibration” period the user must enter their Age and Weight, important variables when calculating calories burnt over a workout. In order to begin the workout, the heart rate sensor must be properly calibrated, so the workout does not proceed until it receives its first message from the Sparkfun (this means that calibration has been a success).



Once calibration is complete, the user's resting heart rate is found using three heart rate readings during the initial rest period. During this time, the application ignores any incoming data about the user's movements.



Once the resting heart rate is found, the user is given their “Calorie Goal” and is prompted during their first “Exercise” period to do a certain exercise.



During this time, the heart rate readings ended up being very inaccurate due to the movement of the user, so I ignored incoming information about heart rate during each exercise period (hence the flat red line starting at $t = 50$). However, movement readings are recorded during the exercise states.

After the first exercise is complete, the user is prompted to rest and record their heart rate readings during this “Rest” state. After these readings are taken, the variables “Average Active Heartrate”, “calories burnt”, and “Grade” are all updated. The image of the fat figure is also changed here depending on how much progress the user has made toward their “Calorie Goal”. The application swaps between exercise and rest states until four sets have been completed.



Once the workout is complete, the user is given a grade based on how many calories they have burned vs. their given calorie goal. Here our user burned 10.3 out of their 15.1 calorie goal, thus receiving a B grade. The figure is also much thinner than it initially was, but still could have been skinnier if the user had worked harder.

